



## House of Barista Knockbox med skuffe 11150005/11150006

**DK**

### INTRODUKTION

For at sikre, at du får størst mulig glæde af din nye knockbox, anbefaler vi, at du gennemlæser denne brugervejledning, inden du tager produktet i brug. Vi anbefaler dig desuden at gemme denne vejledning, hvis du senere skulle få brug for at genopfriske din viden om produktet.

### GENERELLE SIKKERHEDSFORSKRIFTER

- Brug kun produktet til det tilsigtede formål. Producenten er ikke ansvarlig for skader, der opstår som følge af forkert brug eller håndtering.
- Produktet er udelukkende beregnet til husholdningsbrug.
- Produktet må ikke anvendes udendørs- eller til erhvervsbrug.
- Fjern al emballage og alle transportmaterialer fra produktet indvendigt og udvendigt før brug.
- Undersøg produktet for synlige skader og manglende dele.
- Produktet må ikke fyldes med vand eller andre væsker, men må gerne vaskes af i varmt vand og tørres grundig af efterfølgende.

### BRUG AF PRODUKTET

1. Rengør alle dele før produktet tages i brug.
2. Anbring produktet på en tør, plan flade som fx en køkkenbordplade. Sørg for at der ikke er fugtigt under knockboxen.
3. Placér tværstangen i skuffen, og sæt skuffen i holderen. Den lille sikring indvendig i kabinettet sørger for, at skuffen ikke glider ud af kabinettet.
4. Åben nu skuffen og slå din brugte "kaffepuck" ud i skuffen. Undgå at rykke hårdt i skuffen, når du åbner den. Ridser på produktet forårsaget af skuffens slitage på kabinettet, hører ikke under reklamationsretten (se mere under Garantibestemmelser). Kabinettet er indvendigt beklædt med tekstil i bunden for at undgå ridser på selve skuffen/holderen.

5. Kabinettet er udstyret med silikonefodder underne.
6. Tøm jævnlige knockboxen for gamle kafferester. Afskalning af maling er ikke dækket af garantien, da det kan skyldes, at knockboxen har været for fugtig i bunden for længe (se mere under Garantibestemmelser).

### RENGØRING OG VEDLIGEHOLD

- Vask alle delene op i hånden i varmt vand med en smule opvaskemiddel.
- Tør beholder og tværstang rigtig godt af efterfølgende med et viskestykke.

### GARANTIBESTEMMELSER

Garantien gælder ikke:

- hvis ovennævnte ikke iagttages.
- hvis der har været foretaget uautoriserede indgreb i produktet.
- hvis produktet har været misligholdt, været udsat for voldsom behandling eller lidt anden form for overlast.
- Afskalning af maling accepteres ikke som en gyldig reklamationsgrund, da dette kan skyldes at "kaffepucken" har været for våd, eller der har været fugtig i bunden af beholderen i for lang en periode.
- Ridser på produktet forårsaget af skuffens ind- og udtrækning, hører ikke ind under reklamationsretten, da dette anses for at være almindelig slitage.

Grundet konstant udvikling af vores produkter på funktions- og designsiden, forbeholder vi os ret til ændringer af produktet uden foregående varsel.

### OPLYSNINGER OM BORTSKAFFELSE

Produktet skal sorteres som metal og plast.

### Fremstillet i Kina for

Rigtig Kaffe A/S  
Blomstervej 2B  
DK-8381 Tilst

Der tages forbehold for trykfejl.



## House of Barista Knockbox with drawer 11150005/11150006

### UK

#### INTRODUCTION

To get the best out of your new knockbox, please read through these instructions carefully before using it for the first time. We also recommend that you keep the instructions for future reference, so that you can refer to them later.

#### GENERAL SAFETY INSTRUCTIONS

- Use for the intended purpose only. The manufacturer is not responsible for any injury or damage resulting from incorrect use or handling.
- For domestic use only. The product cannot be used for outdoor or commercial use.
- Remove all packaging and transport materials from the inside and outside of the appliance.
- Check that the product has no visible damage and that no parts are missing.
- The knockbox must not be filled with water or other liquids but may be washed off in hot water and dried thoroughly afterwards.

#### USE THE KNOCKBOX

1. Before the first use, clean all parts.
2. Place the product on a dry, level surface such as a kitchen worktop. Make sure there is no moisture under the knockbox.
3. Place the crossbar in the drawer and insert the drawer into the holder. The small stopper inside the holder ensures that the drawer does not slide out of the holder.
4. Now open the drawer and knock out your used "coffee puck" in the drawer. Avoid jerking the drawer hard when opening it. Scratches caused by the wear of the drawer on the holder do not fall under the right of complaint (see more under Warranty Terms). The drawer is lined with textile around the edges to avoid scratches on the container itself.
5. The cabinet is equipped with silicone feet underneath.

6. Empty the knock box regularly for old coffee residues. Peeling paint is not covered by the warranty, as it may be caused by the fact that the knockbox has been too damp at the bottom for too long (see more under Warranty Terms).

#### CARE AND CLEANING

- Wash all parts by hand in warm water with a little dishwashing liquid.
- Wipe the container and crossbar afterwards with a tea dishtowel.

#### WARRANTY TERMS

The warranty does not apply:

- if the above instructions have not been followed
- if any unauthorized interference with the product has occurred.
- if the appliance has been mishandled, subjected to rough treatment, or has suffered any other form of damage.
- Peeling of paint is not accepted as a valid reason for complaint, as this may be due to the "coffee puck" being too wet, or there has been moisture in the bottom of the container for too long time.
- Scratches in paint caused by the drawer being pulled in and out of the holder do not belong under the right of complaint, as this is considered to be normal wear and tear.

Due to the constant development of our products in terms of function and design, we reserve the right to make changes to the product without previous warning.

#### Manufactured in China for

Rigtig Kaffe A/S  
Blomstervej 2B  
DK-8381 Tilst

We cannot be held responsible for any printing errors.